


How to Measure

These measuring instructions apply for all types of window coverings.


- For accurate measurements always use a metal tape measure
- Take measurements in millimetres
- Choose whether you want your blind to fit inside the recess of your window or hang outside the recess overlapping the window
- Always specify the width first, followed by the drop



RECESS

For blinds to hange inside the window recess.

- Measure the width of the window recess in three places as shown
- Measure the drop by taking the measurement from the top of the recess to the window sill, in three places as shown
- Use the smallest measurement
- We will make all adjustments to ensure your blind fits perfectly



BLIND SIZE

For blinds to hang outside the window.

- Measure the exact area you would like the blind to cover as shown
- To minimise light leakage we recommend the blind overlaps by at least 50mm each side

For more information or help with fitting your blinds please call (0)20 8805 8809 or email info@furnishingworkshop.com